



Fan Heater
Тепловентилятор



MR 922

ОПИСАНИЕ

А. Отверстия для выхода воздуха

В. Переключатель ВКЛ./ВЫКЛ.

С. Регулируемый термостат



МЕРЫ БЕЗОПАСНОСТИ

Перед применением прибора внимательно прочитайте всю инструкцию.

Убедитесь, что напряжение сети соответствует напряжению питания прибора.

Всегда отключайте прибор от сети, если он не используется.

Не опускайте прибор в воду или в другие жидкости.

При необходимости отойти, пусть даже на короткое время.

Всегда отключайте прибор от сети.

Особенная осторожность необходима при использовании прибора в непосредственной близости от детей.

Не используйте прибор с поврежденной вилкой или шнуром, при появлении неполадок в работе или после повреждения аппарата.

Для ремонта, обнаружения и устранения неисправностей обращайтесь к авторизованному дилеру фирмы.

Для предотвращения поражения током никогда не разбирайте прибор.

При эксплуатации прибора не препятствуйте выходу воздуха через отверстия.

Следите за тем, чтобы шнур питания не пересекал края стола и не касался горячих поверхностей.

Не используйте прибор вне помещений.

Не устанавливайте нагреватель вблизи от легко воспламеняющихся материалов.

Перед чисткой всегда отключайте прибор от сети.

Если отверстия для входа и выхода воздуха засорились, то

прибор чистку отверстий. Используйте для этих целей пылесос. Перед хранением прибора отключите его от сети питания и дайте ему остыть.

ЭКСПЛУАТАЦИЯ ПРИБОРА

Установите прибор на горизонтальную поверхность и подключите к сети питания.

Выберите нужный режим работы (вентиляция или обогрев) и включите прибор.

ЧИСТКА И УХОД

Электрический тепловентилятор идеально подходит для всех помещений.

Перед чисткой всегда отключайте прибор от сети питания.

Протрите внешнюю поверхность с помощью влажной ткани, смоченной в мыльном растворе.

Перед использованием убедитесь, что внешняя поверхность высохла.

Не используйте абразивные вещества для чистки.

Не разбирайте прибор. Для чистки отверстий для входа и выхода воздуха используйте пылесос.

ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ

Напряжение питания 230 Вольт. 50Герц

Мощность 1000-2000 Ватт

Вес нетто/брутто 1.4 кг /1.7кг

DESCRIPTION

- A. Outlet
- B. Switch Fan /Heat
- C. THERMOSTAT



IMPORTANT SAFEGUARDS

When using electrical appliance when children are present. Basic safety precautions should always be the following.

Read all instructions before using to reduce the risk or electrocution.

Always unplug this appliance immediately after using.

Do not place or store appliance where it can fall or be pulled into a tub or sink.

The appliance should be never left unattended when plugged in. Close supervision is necessary when this appliance is used by or near children or invalids.

Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped into water. Return the appliance to a service center for examination, electrical or mechanical adjustment or repair.

While using this appliance, keep any material away from the air inlets and exhaust outlet.

Do not let cord hang over edge of table or counter or touch hot surfaces.

No maintenance or servicing of this fan heater is required.

Repairs, when necessary, must be performed at authorized service facility.

This fan heater is for household use only.

Never cover air inlet or outlet.

Do not use near inflammable material, curtain, cloth.

Always unplug from electrical outlet before cleaning.

If air is blocked air inlet or outlet, a buildup off-heat inside the heater may activate device to switch off automatically. Remove obstruction. The fan heater will operate normally after a few minutes. Frequently inspect your fan heater for other obstructions. Clean the inlet and outlet regularly. Use cleaner for this proposal. Before storing disconnect the fan heater from electrical socket. Allow it to cool down to room temperature, coil the power cord and place the fan heater in cool area.

HOW TO USE FAN HEATER

Place the unit on level surface and plug into electrical socket.

Switch on and select fan heating. There is 3-position control switch. You can choose high heat, low heat or fan cool.

This fan heater is ideal for dinning room, bedroom, family room, kitchen, office and study class.

CLEANING FAN HEATER

Before cleaning always unplug the fan heater from the electrical socket.

Clean the surface of the fan heater with a sponge or soft rag moistened with mild soap and water solution.

Do not use hard cleaners abrasive detergents or solvents.

Dry the fan heater thoroughly before use.

Do not unscrew the cabinet to clean the inside. Use cleaner for cleaning air outlet and inlet.

Rating 230V, 50Hz

Total Electric absorber Power 1000-2000W

Net /Gross Weight 1.4 / 1.7kg

